
## **Bull's Eye Spirit Levels**

Housing Aluminum, with Mounting Flange, for Mounting with Screws









**30** Angle minutes, bubble move by 2 mm




A Mounting flange for bolting to surface

Page

QVX

**B** Mounting flange for inserting (collar)





d <sub>1</sub>	$d_2$	$d_3$	$d_4$	d <sub>5</sub>	h <sub>1</sub>	h <sub>2</sub>
20	10	14	17	1,8	10	1,8
25	12	17	21	2,2	10	2
30	12	18	24	3,2	11	3
40	20	28	34,5	3,2	14	4
50	25	34	43	3,2	15	5

see also...

## Specification Housing Aluminum Anodized, natural color Anodized, black Spirit level element Glass plastic body Filling Colorless-transparent Casting compound Mineral-based RoHS

## On request

- Filling, green-transparent
- Other sensitivities
- Housing in brass or stainless steel


Bull's eye spirit levels GN 2277 are used to check the horizontal position of jigs, machines, devices, appliances and instruments.

The spirit levels are aligned in relation to the reference surface so that the bubble is located inside the marking ring when the horizontal position of the contact surface is achieved.

GN 2278 Bull's Eye Spirit Levels (for Insertion into Bore Holes)

GN 2279 Bull's Eye Spirit Levels (for Surface Mounting)	QVX
GN 2276 Cross Spirit Levels (for Mounting with Screws)	QVX
GN 2282 Screw-On Spirit Levels (for Mounting with Screws)	QVX
Technical Information	
General Information on Bull's Eye, Screw-On and Cross Spirit Levels	QVX
Accessory	
GN 2277.1 Adjustment Plates	QVX

How to order		Material / Finish	
		d <sub>1</sub>	
		Filling	
		Sensitivity	
		Туре	



## Application example

Bull's eye spirit levels GN 2277 and leveling elements - in this example, leveling elements GN 355 and assembly tool GN 355.1 - are ideal to use when a holding plate is to be brought into an exact horizontal position.

Even after the initial adjustment, the bull's eye level remains in the unit so that the correct alignment can be checked and adjusted again.