



### Installation instructions

Before installation of the position indicator a bore for the torque limiting contact point is to be placed (see left).

With the **adapter bushings GN 952.1** → Page 306, the hollow shaft (with Bore 14 H7) of the position indicator can be adapted to fit the spindle.

If a reduction in the diameter of the hollow shaft is to be made at the same time as mounting a control knob, **control knobs GN 957** (→ Page 307) are available which combine both functions in a single component (no adaptor bushings required).

Before completing the installation, turn the spindle to the starting point (0) position and zero the position indicator.