

### **Specification**

- Bearing bushing / Cover cap Plastic
  (2) (2) (3) (4)
- Technopolymer (Polyamide PA) Graphite gray, RAL 7024
- Tapered dowel pin ISO 8741 Steel
  Zinc plated, blue passivated
- Plastic Characteristics → Page 2158
- RoHS

#### Information

2

GR

Bolt sets GN 2290 are designed as accessories for GN 2291 hinge wings for mounting individual hinge versions.

Bolt sets with identification no. 1 are designed for hinges with two hinge wings, bolt sets with identification no. 2 and 3 are designed for hinges with three hinge wings. Bolt sets with identification no. 2 are used exclusively for short middle wings with a length of 40 mm. Bolt sets with identification no. 3 must be used for longer middle wings.

#### see also...


- Hinge Wings GN 2291 → Page 1318
- Hinges GN 2292 (with Guide Step)  $\rightarrow$  Page 1380
- Hinges GN 2294 → Page 1381
- Hinges GN 2295 (Three-Part) → Page 1314 / 1315

How to order	1	Identification no.
GN 2290-1-GR	2	Color



## Mounting information

Door to be unhinged



### Left / right hinges


Right or left hinges can be created by the direction in which the bearing bushings are inserted into the hinge wing.

# Cabinet U-handle GN 565.1

# Mounting on door frames

For mounting a door that should be removable, two hinges of the same type must be attached to the door frame.

If the door is not supposed to be removable, the door must be mounted with at least one right hinge and at least one left hinge.



## Mounting

Door not to be unhinged

- 1. Position the bearing bushing with the desired installation direction on the hinge wing. Then insert a screw with a collar such as socket button head screws ISO 7380 into the bearing bushing to protect the bearing bushing collar from damage while pounding in.
- 2. Pound in the bearing bushing until about 1 mm remains between the bearing bushing collar and the hinge wing.
- 3. Remove the burr on the bearing bushing using a knife.
- 4. Pound in the bearing bushing all the way.
- 5. Remove the screw.
- 6. Pound a tapered dowel pin into the bearing
- 7. Place the cover cap on the opposite side of the hinge wing.

Insert the other bearing bushings according to points 1 to 5.

