



3.1

3.2

3.3

3.4

3.5

3.6

Assembly instructions

The assembly of the oil level indicators GN 650 is very simple and economical. You need two drillings $\varnothing 10,5$ and/or $\varnothing 12,5$ mm in the distance l_1 in the container wall. The oil level indicator can also be installed directly i.e. without nut, if the container wall has a fitting thread.

All individual parts necessary for the assembly are provided: Hexagon nuts, O-rings and serrated lock washers for safe guard. For perfect sealing by the O-rings the screws should not be too strongly tightened (max. 12 Nm). Recommended roughness of the sealing surface $RA = 3 \mu\text{m}$.

3.7

3.8

3.9

