



Mounting information

- 1) Drill the handle housing according to the template dimensions reported in the table.
- 2) Remove all drilling burrs before fitting the handle.
- 3) Fit the frontal body of the handle into the housing of the panel.
- 4) Fit the rear body of the handle onto the rear panel and press until the complete fitting with the frontal handle part.
- 5) Fit the two bodies with self-tapping screws.

