
Housing Brass, for Mounting with Screws







## Sensitivity

- 6 Angle minutes, bubble move by 2 mm
- **50** Angle minutes, bubble move by 2 mm

## 5 Identification no.

- Viewing window top
- 2 Viewing window top front
- 3 Viewing window top - front - back

<b>Y</b>						
I <sub>1</sub>	b	d	h <sub>1</sub>	h <sub>2</sub>	I <sub>2</sub>	m
57	12	4,5	13	1	37	45

## Housing Aluminum • Anodized, natural color • Anodized, black Spirit level element • Glass plastic body • Filling Green-transparent G Casting compound Mineral-based RoHS

On	request	

- Filling, colorless-transparent
- Other sensitivities
- Other colors

2

Specification

Screw-on spirit levels GN 2282 are used to check the horizontal position of jigs, machines, devices, appliances and instruments.

The spirit levels are aligned in relation to the finished reference surface so that the bubble is centered in the middle of the marking lines once the horizontal position of the contact surface in the longitudinal direction is reached.

see also	Page
GN 2283 Screw-On Spirit Levels (for Mounting with Screws)	QVX
GN 2276 Cross Spirit Levels (for Mounting with Screws)	QVX
GN 2280 Bull's Eye Spirit Levels (Adjustable)	QVX
Technical Information	
General Information on Bull's Eye, Screw-On and Cross Spirit Levels	

How to order	1	Material / Finish
		I <sub>1</sub>
	3	Filling
1 2 3 4 5	4	Sensitivity
GN 2282-MSR-57-G-50-3		Identification no.

