

8.1

8. 2 2

ຕ ຕ

3.4

3.5


3.6

0


ന്

١Ā

## Electrical data




## Assembly sequence for the cable connection



- 1. Loosen the mounting screw and pull off the connector plug.
- 2. Push the contact holder out of the connector casing.
- 3. Loosen the cable gland, feed the cable through the connector casing and connect it to the contact holder.
- 4. Push the contact holder back into the connector casing and tighten the cable gland to the strain relief / sealing of the cable.
- 5. Push the connector plug onto the connecting contacts of the float switch and secure in place with mounting screws.

## Assembly sequence GN 654 / GN 654.1



- 1. Remove the end piece of the oil level indicator.
- 2. Insert and correctly position the float with the marking "UP" pointing up.
- 3. Push on the switchgear unit.
- 4. Fix the switchgear unit in the desired position and re-assemble the end piece.
- 5. Mount the oil level indicator in the reservoir wall using both plastic spacer rings if the reservoir is made of ferromagnetic material.
- 6. Mounting the cable connection.