


Application example



d ₁	b	d ₂	h ₁	h ₂	h ₃	A/F	Max. permissible torque in Nm
12	2	11	35	7	6	8	20
18	2	17	39	8	9	11	50
24	4	22,5	43	9	12	13	75
30	4	28,5	48	11	15	17	100
36	4	34,5	53	13	18	22	150

Specification

- Steel
 - Surface hardened
 - Backened
- RoHS

Information

Assembly tools GN 355.1 serve to adjust leveling elements GN 355 / GN 355.2. They are used in connection with a T-wrench or a hexagonal angle socket spanner. To ease leveling, the top end of the assembly tool has an external hexagon head which is used for turning the leveling screw with a ring spanner, ideally with a ratchet function.

For adjustment, first use the assembly tool to turn the leveling screw of the leveling element into the desired position and at the same time tighten the screw to secure the leveling element. To ensure that the setting found does not change, the assembly tool may be used to counterhold.

How to order

GN 355.1-36

1 d₁

3.1
3.2
3.3
3.4
3.5
3.6
3.7
3.8
3.9

